



Switch type: 3way toggle switch.
 Position 1: Bridge.
 Position 2: Bridge and neck in parallel.
 Position 3: Neck.
 Notes: Push/pull tone pots for coil split.